

Connector Codes

CONNECTOR NUMBER	NO. OF PINS	CIRCUITS
C1	2	Left front parking and turn signal lights
C2	1	Left front side marker light
C3	2 }	Left headlight motor
C4	2 }	
C5	2	Cooling fan thermoswitch
C6	2	Cooling fan motor
C7	2 }	Right headlight motor
C8	2 }	
C9	2	Left front parking and turn signal lights
C10	1	Right front side marker light
C11	5 }	Instrument cluster
C12	5 }	
C13	8 }	
C14	6	Turn signal switch, horn button, and windshield washer
C15	5	Headlight high/low beam changeover switch and horn button
C16	8	Windshield wiper switch
C17	6	Windshield wiper motor
C18	4	Ignition switch
C19	2	Remove key switch
C20	4	Terminal board for power distribution
C21	3	Panel light rheostat
C22	1	Courtesy panel light
C23	2	A.C. controls
C24	12	Rear tail lights, fuel gauge, tachometer, oil pressure sending unit, alternator, water temperature sending unit, and gulp valve
C25	12	Radio speakers, carburetor or fuel injectors cooling fan, starter, ignition system, idle stop solenoid, rear window defogger, courtesy light, and handbrake switch
C26	1 }	Driver's seat belt switch
C27	1 }	
C28	3	A.C. minimum pressure switch
C30	1	Electronic ignition module
C31	1	
C32	2	A.C. panel lights
C33	1 }	Alternator
C34	1 }	
C35	1 }	License plate lights
C36	1 }	
C37	—	
C38	1	Gulp valve
C39	—	
C40	2	Back-up light switch
C41	1	Carburetor or fuel injector cooling fan
C42	4	Digital clock
C43	—	
C44	—	
C45	1	A.C. compressor
C46	2	A.C. blower
C47	6	A.C. controls
C48	2	A.C. high pressure switch
C49	2	A.C. condenser fan
C50	2	A.C. condenser fan thermoswitch
C51	5	Lambda sensor indicator switch unit